

1. Put the canopy 2 on the nipple1, then secured by hex nut2
2. Put the canopy 1 and washer on the nipple 1, then secured by hex nut1
3. Put the tube 6 on the coupler 1, then lock the tube to the tube 4 till tighten, the balance 3pcs tubes are locked one by one
4. Place the tube 3 and shade on the socket.

