

## Assembly Instruction For 13506

- 1. Thread the nipple into the coupler then secure by hex nut.
- 2.Attached the cap,top part on the nipple then secure by loop.

3.Place the glass cover the socket then secure by socket ring.

