



Assembly Instruction For 13507

1. Thread the nipple into the coupler then secure by hex nut.
2. Attached the cap, top part on the nipple then secure by loop.
3. Attached the glass cover the socket then secure by socket ring.

