

Assembly Instruction For 13560

- 1. Turn the nipple into the coupler then tighten it with the hex nut;
- 2. Attach the glass and the rubber washer and the meter washer to the nipple with the nut;
- 3. Attach the cap to the nipple with the finial.

