

# MAXIM Assembly Instruction For 21344

1. Place cap(C) into metal(E) ;then secured coupler(D) by tube(B).
2. Secured tube(B) by loop(A).
3. Secured coupler(F) by nipple(H);then secured nipple(H) by hexnut(G).
4. Place tube(I),cap(J),metal cap(K) into nipple(H);then secured nipple(H) by hexnut(G).
5. Place glass shade(L) into metal(E) .
6. Place cap(M) into nipple(H);then secured nipple(H) by nexnut(G).
7. Place metal shade(O) and cap (P) into metal(E);then secured nipple(H) by ball(Q).

