

Assembly Instruction For 22264

- 1. Thread the nipple 1 on the coupler 1 then fix it by
- 2.Attach the cover1 and poly column to the nipple then secured the loop
- 3. Thread the nipple 2 to the coupler 2 then fix it by hex nut nut 1
- 4. Attach the cover2 on the nipple2 then secured by finial
- 5. Attach the glass to the socket then secured by socket ring
- 6. Hang the crystal to the ring of the arm

