

Assembly Instruction For 22268

- 1. Spaced the arms level
- 2. Thread the nipple to the coupler then fix it by Hex nut1
- 3. Attach the poly column to the nipple the secure by loop
- 4. Thread the nipple 2 to the coupler 1 attach the cover to the cover 1 the secure by finial
- 5. Thread the nipple 3 to the coupler 2 the secure by finial 1
- 6. Hang the crystals to the rings of the arm one by one
- 7. Attach the glass to the sockets then secure by socket ring

