

# MAXIM Assembly Instruction For 22303PN

1. Through the screw (C) to steel shade (O), cross spider(D) and the metal washer (R), ; then secured by ball (S) till tight
2. Insert the decorated part (F) to the cross spider(D), put the cap(H), tube(I) to the decorated part(F), then secured by socket (L)
3. Secured the tube (E) to the decorated part(F)
4. Secured the tube (B2) to the tube (E)
5. Secured the tube (B1) to the tube (B2)
6. Secured the tube (B) to the tube (B1)
7. Secured the ceiling pan (A) to the tube (B)
8. Secured the nipple(Q) to the coupler (L); then secured by hex nut (P) till tight
9. Put the rubber washer (M1), glass diffuser (X), rubber washer (M) and metal washer(N) to the decorated flat metal; (Z), the secured by nut (V) till tight
10. Put the metal washer (W) and rubber washer (U) to the nipple (Q)
11. Put the glass diffuser (X) and decorated flat metal(Z) into the steel shade(O), and put the metal washer(W1) and the rubber washer (U1) to the nipple (Q), then secured by the hex nut(P1) till tight
12. Put the cap (T) to the glass diffuser (X); then secured by part (Y) till tight
13. Install 5\*60W type A bulbs into socket of the fixture(bulbs not included)

