

## Assembly Instruction For 88536SWAE

- 1. Attach the glass ( C ) and bottom cover ( B ) to the fixture ( D ).
- 2. Thread the screws (A) from the hole of bottom cover to the hole (E) on the fixture till tight.

