

Assembly Instruction for  
8911,8912

(1) Spread the arm evenly. Make sure each arm is aligned with the center rod

(2) Use the screws prepared in the parts bag to tighten the arms and top body

