

Assembly Instruction For 12027

- 1. Put the nipple 1 into the coupler and secured by hex nut,
- 2. Place attached the cover 1, poly column, and secured by loop
- 3. Put the cover 2 on the nipple 2, then secure by ball nut 2
- 4. Put the nipple 3 through the flat metal and cover 4, then secured by ball nut 1
- 5. Attached the cover 3 on the nipple 3, then secured by ball nut 3
- 6. Place the arm level, then put tube on the socket
- 7. Hang the crystal 1 and crystal 2 into ring

