

Assembly Instruction For 12219

- 1.Attached the top arm on the nipple 1 then secure by tube.
- 2. Attached the cap on the nipple 2 then secure by finial.

