

1. Spread the arms evenly, make sure each arm is aligned with the center rod.
2. Turn the nipple 1 into the coupler 1.
3. Attach the poly column on the nipple 1 then secure by the loop.
4. Turn the nipple 2 into the coupler 2.
5. Attach the cap on the nipple 2 then secure by the hex nut.
6. Screw the finial on the nipple 2.
7. Attach the glass on the socket then secure by the socket ring.

