

Assembly Instruction For21263

- 1. Screw the nipple 1 into the coupler.
- 2. Attached the cover to the nipple 1 then secure by the loop.
- 3.Attach the rubber washer 1 to the nipple 3 then attach the nipple to the combination.
- 4. Attach the rubber washer 2 to the glass then fix the combination and glass by hex nut and finial.
- 5. Attach the diffuser to the nipples 2 then secure by the balls 1.

