



Assembly Instruction For 5855

1. Screw the nipple into the coupler then secure by hex nut 1.
2. Attached the glass, rubber washer and metal washer on the nipple then secure by hex nut 2.
3. Attached the cap on the nipple then secure by finial.

