

1. Turn breaker off for circuit on outlet where fixture is to be installed.
2. Remove mounting bracket from fixture and install to electrical box.
3. For "Wet Location" installations it is necessary to install clear gasket to bottom edge of canopy
4. Wire fixture to wires in outlet box. Green wire is for Ground.
5. Install fixture to bracket and tighten screws in the canopy to secure.
6. Re-install lens to fixture turning clockwise

This fixture is designed to dim with a standard Triac forward phase dimmer. Dimming levels will vary by dimmer. Below is a list of recommended dimmers:

- Lutron MACL-153M                      Lutron DVL-153P
- Lutron SCL-153P                      Leviton IPL06-10Z
- Leviton 6674-POW

Due to the inrush current, wattage should not exceed 150 watts of product for a 600 watt dimmer.

