

Assembly Instruction For 91102

1, Put the iron ring on the glass.

2,Attach the glass and glass cover on the socket then tighten them with socket ring.

