



## Installation Instructions Model 91700CLPC

1. Turn breaker off for circuit on outlet where fixture is to be installed.
  2. Install mounting bracket to electrical box.
  3. Wire fixture to wires in outlet box. Green wire is for Ground.
  4. Install fixture to bracket and tighten mounting nuts so that fixture meets the wall.
  5. Install inner crystal strings A to metal loops on top pan. It is recommended to use glove included and not touch crystal with bare fingers
  6. Install 40 watt G9 xenon bulbs by gently pushing into socket.
- (Caution: Xenon bulbs get very hot and may burn you. Always make sure bulbs are off for a minimum 10 minutes before handling)

