






1. Turn breaker off for circuit on outlet where fixture is to be installed.
2. Remove X bracket from fixture and install to electrical box
3. Mark 4 holes on outer slots of bracket for hollow wall anchors
4. Remove X bracket from outlet
5. Drill 4 x 1/8" holes and insert hollow wall anchors
6. Reinstall X bracket to outlet and secure bracket to ceiling using 4 screws included into hollow wall anchors
7. Wire fixture to wires in outlet box. Green wire is for Ground.
8. Install fixture to bracket and tighten 4 nuts so that fixture meets the ceiling.
9. Install GU10 light bulb by inserting into socket and twist lock into place.
10. Install strings of glass onto pan. Fixture is a random design and can be adjusted to your liking.

GU10 halogen bulbs can be dimmed using standard triac dimmers. It is recommended that GU10 LED bulbs be dimmed using Lutron CL dimmers





Contemporary
Lighting™

Installation Instructions

Model 39850PCPC



















CRY Code	MAXIM CRY#	CRY Code	MAXIM CRY#
1	CRS39850PC01	35	CRS39850PC35
2	CRS39850PC02	36	CRS39850PC36
3	CRS39850PC03	37	CRS39850PC37
4	CRS39850PC04	38	CRS39850PC38
5	CRS39850PC05	39	CRS39850PC39
6	CRS39850PC06	40	CRS39850PC40
7	CRS39850PC07	41	CRS39850PC41
8	CRS39850PC08	42	CRS39850PC42
9	CRS39850PC09	43	CRS39850PC43
10	CRS39850PC10	44	CRS39850PC44
11	CRS39850PC11	45	CRS39850PC45
12	CRS39850PC12	46	CRS39850PC46
13	CRS39850PC13	47	CRS39850PC47
14	CRS39850PC14	48	CRS39850PC48
15	CRS39850PC15	49	CRS39850PC49
16	CRS39850PC16	50	CRS39850PC50
17	CRS39850PC17	51	CRS39850PC51
18	CRS39850PC18	52	CRS39850PC52
19	CRS39850PC19	53	CRS39850PC53
20	CRS39850PC20	54	CRS39850PC54
21	CRS39850PC21	55	CRS39850PC55
22	CRS39850PC22	56	CRS39850PC56
23	CRS39850PC23	57	CRS39850PC57
24	CRS39850PC24	58	CRS39850PC58
25	CRS39850PC25	59	CRS39850PC59
26	CRS39850PC26	60	CRS39850PC60
27	CRS39850PC27	61	CRS39850PC61
28	CRS39850PC28	62	CRS39850PC62
29	CRS39850PC29	63	CRS39850PC63
30	CRS39850PC30	64	CRS39850PC64
31	CRS39850PC31	65	CRS39850PC65
32	CRS39850PC32	66	CRS39850PC66
33	CRS39850PC33	67	CRS39850PC67
34	CRS39850PC34	68	CRS39850PC68



Contemporary
Lighting™

Installation Instructions

Model 39850PCPC







Contemporary
Lighting™

Installation Instructions


Model 39850PCPC




CS39850PC191PC
L: 14.17"




CS39850PC201PC
L: 52.56"




CS39850PC211PC
L: 19.49"




CS39850PC221PC
L: 33.07"




CS39850PC231PC
L: 56.71"




CS39850PC241PC
L: 16.94"




CS39850PC251PC
L: 62.4"



CS39850PC261PC
L: 30.71"




CS39850PC271PC
L: 53.15"




CS39850PC281PC
L: 18.7"




CS39850PC291PC
L: 40.35"




CS39850PC301PC
L: 28.74"




CS39850PC311PC
L: 61.22"




CS39850PC321PC
L: 49.61"




CS39850PC331PC
L: 38.88"




CS39850PC341PC
L: 19.49"




CS39850PC351PC
L: 34.06"




CS39850PC361PC
L: 48.23"




CS39850PC371PC
L: 12.8"




CS39850PC381PC
L: 44.29"




CS39850PC391PC
L: 17.52"




CS39850PC401PC
L: 32.48"




CS39850PC411PC
L: 56.26"




CS39850PC421PC
L: 16.94"



CS39850PC431PC
L: 16.73"



CS39850PC441PC
L: 28.74"





CS39850PC451PC
L: 43.77"



Contemporary
Lighting™

Installation Instructions

Model 39850PCPC






















Contemporary
Lighting™

Installation Instructions

Model 39850PCPC







Contemporary
Lighting™

Installation Instructions

Model 39850PCPC







Contemporary
Lighting™

Installation Instructions


Model 39850PCPC




CRS39850PC46+1PC
L: 17.91"




CRS39850PC47+1PC
L: 58.27"




CRS39850PC48+1PC
L: 19.49"




CRS39850PC49+1PC
L: 43.11"




CRS39850PC50+1PC
L: 16.54"




CRS39850PC51+1PC
L: 26.18"




CRS39850PC52+1PC
L: 15.55"




CRS39850PC53+1PC
L: 60.43"




CRS39850PC54+1PC
L: 27.17"




CRS39850PC55+1PC
L: 45.08"




CRS39850PC56+1PC
L: 59.06"




CRS39850PC57+1PC
L: 18.5"




CRS39850PC58+1PC
L: 28.94"




CRS39850PC59+1PC
L: 61.61"




CRS39850PC60+1PC
L: 17.72"




CRS39850PC61+1PC
L: 22.83"




CRS39850PC62+1PC
L: 40.94"




CRS39850PC63+1PC
L: 57.48"




CRS39850PC64+1PC
L: 17.72"




CRS39850PC65+1PC
L: 25.39"



CRS39850PC66+1PC
L: 60.83"



CRS39850PC67+1PC
L: 41.54"



CRS39850PC68+1PC
L: 48.62"