





PRODUCT NAME:Hennesy
ITEM NUMBER: 43441

Please consult your electrician for hanging fixture and wiring.



Bulb(included): 2 x GU24 LED 9W


IMPORTANT: Turn off the power at the main fuse or circuit breaker box before starting installatio



(A)GU 24 Bulb




(B)Shade




(C)Body

Locate all hardware & components before discarding packaging




1.)




Step.1:Remove mounting bracket from fixture and install to electrical box

2.)



Step.2:Wire fixtures to wires in outlet box. Copper/green wire is for ground. Install body (C) to bracket and tighten screws on the backplate to secure.

3.)



Step.3: Secure the lamp shade (B) to the body (C) using the screw ring around the socket. Install the LED GU24 bulbs (A) provided.

Cleaning & Care:
Clean with soft cloth and a mild detergent.
Do not use abrasive cleaner.